
2050-SA INSTALLATION INSTRUCTIONS




When installing unit through a manhole cover & frame, you will need to follow these instructions. Remove lid to unit and remove the media cartridge, glue and intake valves.



Lower unit body vertically into manhole.



Place a bead of glue on the inside of the vacuum intake valves.



Install intake valves on intake tubes.



Install media canister into unit.



Install unit lid and fasten latches.

2050-SA Maintenance Guide

- Mist eliminator pad should be removed and washed out periodically.
- To increase the longevity of the media, we recommend every 6 months removing the canister and shaking up the contents. This gives the media pellets a new surface to scrub H2S gas.
- Inspect drain for any blockage.

